





**Cordless Drill** 

TE-CD 18/40 Li-Solo

Item No.: 4513925

Ident No.: 11018

Bar Code: 4006825635768

WER CHANGE

The Einhell TE-CD 18/40 Li-Solo cordless drill from the PXC family is indispensable for screwdriving and drilling work around the home and in the workshed and garage. The 2-speed gearing for powerful drilling and screwdriving is finely regulated by the electronic speed control, so that the cordless drill can be adjusted to the specific task for each material and application. The cordless drill is always ready-for-use thanks to the li-ion technology with zero self-discharge. Optimum use in dark areas is ensured by the LED lighting. For exceptionally easy handling it has an ergonomic design and softgrip. The rechargeable battery and charger are available separately, e.g. as a practical PXC starter set.

## **Features & Benefits**

- A member of the Power X-Change family
- 2-speed gearing for powerful drilling and screwing
- Speed electronics for material and application suitable working
- Always Ready-for-use due to Li-ion technology without discharging
- LED lighting for optimum operation in dark areas
- Extremely easy to work with due to ergonomic design and Softgrip
- Battery and charger are available separately.

## **Technical Data**

- Number of gears

- Idle speed (gear 1) 400 min^-1 - Idle speed (gear 2) 1500 min^-1 40 Nm - Max. torque hard - Number of torque steps 21 settings

- Drill chuck 13 mm | single sleeve

## **Logistic Data**

- Product weight 1.07 kg - Gross weight single packaging 1.47 kg

- Dimensions single packaging 199 x 82 x 195 mm

- Pieces per export carton 4 Pieces - Gross weight export carton 4.1 kg

- Dimensions export carton 350 x 215 x 215 mm 6880 | 13848 | 16772 - Container quantity (20"/40"/40"HC)

















## Available as special accessories



Bit-Set, 23-teilig Cordless Drill Accessory Item No.: 4258073 Bar Code: 4006825573268

Einhell Grey



18V 1,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512021 Bar Code: 4006825601350 **Einhell Accessory** 



18V 4,0 Ah Power-X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 **Einhell Accessory** 



18V 3,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512041 Bar Code: 4006825613698 Einhell Accessory



18V 2,6Ah P-X-C Plus Battery Item No.: 4511436 Bar Code: 4006825616590 Einhell Accessory



18V 5,2 Ah P-X-C Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



Power-X-Twincharger 3 A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



Drill and bit set, 70 pcs Power Tools Accessory Item No.: 4258085 Bar Code: 4006825563610 Einhell Grey



18V 2,0 Ah Power-X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory



18V 4,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



18V 30min Power-X-Change Charger Item No.: 4512011 Bar Code: 4006825587029 Einhell Accessory



Power-X-Boostcharger 6 A Charger Item No.: 4512064 Bar Code: 4006825629019 Einhell Accessory